



Flow Line Options

# MEMFloThru-View Panel Mounting Kit Instruction Manual



Fig 1


The panel mounting bracket has been supplied for mounting the MEMFlo flow meters behind the panel for easy mounting and viewing.

Before the MEMFlo flow meter has been connected to the pipe, the panel mounting ring should be attached and secured to the MEMFlo flow meter using a  $\frac{1}{4}$  - 20 hex head driver with the hex head locking screw supplied. The mounting ring is attached to the lower half of the meter body as pictured in FIG.1.

Please see the panel mounting diagram on the next page for panel cutouts. Drill holes as indicated and cutout a panel window as indicated on the dotted lines of the diagram.

A window has been provided to cover the panel cutout and to view the flow meter sight tube and scale. Once the mounting holes have been drilled per the diagram and the panel cutout has been made, attached the window to the panel using  $\frac{1}{4}$ -20 screws supplied and mount the MEMFlo flow meter in your piping system.

Figure 2



<b>FLOW LINE OPTIONS CORPORATION</b>	
Description:	DRW.#
9009 FREEWAY DR. MACEDONIA, OHIO 44056	BY:
(330) 468-0180 WWW.FLO-CORP.COM	